





HD006NHB



SP20MM1420



SP-1420-SCREW

Includes:

- 1 - Camera Mounting Bolt to 1/4"-20 Adapter (SP-1420-SCREW)
- 1 - Multi-Angle Mounting Pedestal (HD006NHB)
- 1 - 20mm Metal Ball to 1/4"-20 Camera Adapter (SP20MM1420)


Compatibility: Suitable for GoPro® HERO® action cameras and other cameras compatible with 1/4"-20 mounts.

Please note the HD006NHB hardware specifications:

- 4 - Philips M4 coarse 22mm
- 4 - Philips M4 coarse 26mm
- 4 - M4 Drill wall anchors 26mm


1 Assemble the camera adapter to the mounting pedestal

Begin by loosening the knob in a counter-clockwise direction to attach the 20mm ball adapter to the mounting pedestal.




2 Assemble the camera bolt to the mounting pedestal

Attach the camera bolt to the mounting pedestal by inserting it and twisting it clockwise to secure the position.




3 Mount Installation

Utilize the hardware included with the pedestal to securely attach it to the mounting surface. If needed, employ anchors for added stability.



4 To mount a camera

Remove the side screw and attach a GoPro HERO (sold separately) to the adapter. Then, secure the side screw back in place. Finally, adjust the pedestal to your preferred position by loosening the center knob, then tighten it again.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

