

HD007

SP20MM1420

SP-1420-SCREW

## Includes:


- 1 - Camera Mounting Bolt to 1/4"-20 Adapter (SP-1420-SCREW)
- 1 - 8" Multi-Angle Clamp Pedestal (HD007)
- 1 - 20mm Metal Ball to 1/4"-20 Camera Adapter (SP20MM1420)

**Compatibility:** Suitable for GoPro® HERO® action cameras and other cameras compatible with 1/4"-20 mounts.

**Note:** C-Clamp opening: 0" - 1 5/8" (0mm - 41mm)


### 1 Assemble the camera adapter to the mounting pedestal

Loosen the knob in a counter-clockwise direction and attach the 20mm ball adapter, removing the Dual T-Tab adapter from the pedestal.




### 2 Assemble the camera bolt to the mounting pedestal

Attach the camera bolt to the mounting pedestal by inserting it and twisting it clockwise to secure the position.




### 3 Mount Installation

Secure the pedestal clamp by rotating the c-clamp knob and positioning the clamp bracket accordingly.



### 4 To mount a camera

Remove the side screw and attach the GoPro HERO (sold separately) to the adapter. Then, secure the side screw back in place. Finally, adjust the pedestal to your preferred position by loosening the adjustment knobs, then tighten them again.



#### WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

#### WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

