

## Includes:

- 1 - MagSafe Magnet Adapter with Tightening Ring (SPMAGS01)
- 1 - Adhesive Magnetic Ring - Optional
- 1 - 11" Tripod with 1/4" -20 camera pattern (CMPTRIXL)
- 1 - Carrying Bag (CAMPOUCHXL)
- 1 - 1/4" - 20 Camera Bolt with 17mm Ball Adapter (AP142017MM)


**Important:** Clean the application surface before applying the optional magnetic ring.

**Important:** If using the optional magnetic ring, please press the adhesive back side to the application surface firmly. Allowing 24 hours for the adhesive to cure before using.


- 1 Attach the Camera Adapter to the Tripod Mount**  
Secure the camera adapter with the 17mm ball by screwing it onto the mounting bolt of the tripod.




- 2 Attach the MagSafe Magnetic Holder to the 17mm Ball**  
Position the tightening ring over the 17mm ball adapter on the tripod mount. Insert the magnetic holder into the 17mm ball. Secure the connection by tightening the ring in place.



- 3 Optional - Installing the Magnetic Ring on Your Device**  
To attach the adhesive magnetic ring to your non-magsafe smartphone case, just remove the yellow sticky side and apply to the back of your device.



- 4 Mounting Your Phone on the Mount**  
Ensure the magnetic ring of your MagSafe compatible device is aligned with the holder for a secure fit.



### WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

### WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.