

Includes:

- 1 - Slim-Grip® Tablet Holder with Support Legs (TAB001)
- 1 - Long Arm Dashboard Pedestal with Dual-T Adapter (CM117-SBH)
- 1 - Alcohol Pad (XACP)

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.

Please note the TAB001 packaging includes:

- 5 - Support Stoppers (SP-TABS5PK) - Optional


Leg selection guide

Recommended legs to use based on tablet with or without a case

- For tablets size min 6" to 8.25" max we recommend using 4 small legs
- For tablets size min 6.75" to 9.12" max we recommend using 2 small legs and 2 medium legs
- For tablets size min 8.31" to 10.75" max we recommend using 2 medium legs and 2 large legs
- For tablets size min 9.12" to 11.50" max we recommend using 4 large legs


1 Install the holder to the mounting pedestal

Insert the Dual T-Tab head of the pedestal to the back of the holder. Then, slide the holder upwards to ensure it is securely in place.




2 Remove the protective film from the mount

Peel off the clear protective sheet from the base, then firmly press the suction cup base onto the adhesive disk. Secure the suction cup in place by flipping the lever downward to lock it.




3 Installing the legs to the holder

Install the support legs required based on the recommendations listed above. Slide the support legs into the holder's support leg channels.



4 Extend the spring-loaded mechanism

To extend the legs, insert one end of the tablet into the bottom support legs.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING


Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

Continued on page 2




5 Install the tablet

With the holder's spring-loaded support legs expanded, lay the tablet flat on the holder. Gently release the tablet into the holder, allowing the bottom spring-loaded support legs to secure the tablet.




6 Expanding the length of a mount

To increase the mount's length, pull up the middle level to extend the arm. Once you have reached the desired length, push the lever back down to lock it in place.




7 Adjusting the mount

To adjust the mount's position, rotate the knob counterclockwise. After choosing the desired angle, turn it clockwise to lock it in place.



8 Fully Assembled

Refer to the image below for the full assembled product.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

