


TABPBRM023 | Push-Button Tablet Holder with Cup Holder Mount



Includes:

- 1 - Universal Push-Button Tablet Holder (TAB003)
- 1 - 25mm Ball to Dual T-Tab Mounting Pattern Adapter (APRM2T)
- 1 - Robust™ Series 3.75 inch Mount Shaft Arm (SP-RM250)
- 1 - Cup Holder Mounting Pedestal (SPRM023)


Please take note of the pads included in SPRM023 packaging:

- 1 - Set of 4 Self-Adhesive Pads (SP023PAD) - Optional


Compatibility: This holder is suitable for tablets with cases measuring up to 6.5" tall.

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.

- 1 Install the Dual T-Tab adapter into the tablet holder**
Insert the Dual T-Tab adapter into the slot located behind the holder. Then, slide the adapter upwards to ensure it is securely in place.



- 2 Assemble the components**
Turn the shaft knob counterclockwise to loosen it. Next, attach the 25mm ball adapters to both ends. Finally, tighten the shaft to secure everything in place.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

Continued on page 2

ARKON® MOUNTS

USA (800) 841-0884
INT'L (626) 254-9005
Monday - Friday 9 am - 5 pm PST

arkon.com
Designed in USA
©Arkon Resources, Inc.


Need assistance?
Scan to email our
Arkon® customer
service team.



3

Fully Assembled


Refer to the image below for the full assembled product.



4

Expand Your Cup Holder


To adjust the base to fit your car's cup holder area, simply twist it counterclockwise. In case of oversized cup holders, utilize the adhesive pads included in the package.



5

Adjusting the Tablet Holder


To extend the tablet holder, simply press the button. This will engage the spring-loaded mechanism, making it simple to insert and remove your tablet.



6

Install your device into the Push-Button Tablet Holder

Place your device in the holder and push the top down to firmly secure your tablet in place.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

