

Includes:


- 1 - Slim-Grip® Universal Tablet Holder with Support Legs (TAB001)
- 1 - 1/4"- 20 Camera Bolt with 22mm Ball Adapter (AP142022MM)
- 1 - Dual T-Tab with 22mm Ball Mount Adapter (SP-SB-2T-22)
- 1 - 22mm compatible Tightening Ring (SP-SB-RING-22)

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.


Leg selection guide

- Recommended legs to use based on tablet with or without a case
- For tablets size min **6" to 8.25"** max we recommend using 4 small legs
 - For tablets size min **6.75" to 9.12"** max we recommend using 2 small legs and 2 medium legs
 - For tablets size min **8.31" to 10.75"** max we recommend using 2 medium legs and 2 large legs
 - For tablets size min **9.12" to 11.50"** max we recommend using 4 large legs


- 1** **Attach the Camera Mounting Adapter to the Tripod**
Fasten the camera mounting adapter by screwing it onto a tripod's mounting bolt (**tripod not provided**).




- 3** **Attach the Components**
Position the tightening ring over the 22mm ball adapter. Then, attach the back of the tablet holder to the 22mm ball. Lastly, ensure a firm connection by securely tightening the ring.



- 2** **Install the Dual T-Tab adapter into the tablet holder**
Insert the Dual T-Tab adapter into the slot located behind the holder. Then, slide the adapter upwards to ensure it is securely in place.



- 4** **Fully assembled**
Refer to the image below for the full assembled product.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system


WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation

Continued on page 2




- 5** **Installing the legs to the holder**
 Install the support legs required based on the recommendations listed above. Slide the support legs into the holder's support leg channels.




- 6** **Extend the spring-loaded mechanism**
 To extend the legs, insert one end of the tablet into the bottom support legs.



- 7** **Install the tablet**
 With the holder's spring-loaded support legs expanded, lay the tablet flat on the holder.



- 8** **Release the tablet to secure**
 Gently release the tablet into the holder, allowing the bottom spring-loaded support legs to secure the tablet.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

