


HD008 | Weighted Base Stand with Dual-T Mounting Pattern




Includes:

- 1 - Short Pole (SPHD8STM)
- 1 - Weighted Base (SPHD8BASE)
- 1 - 20mm Ball to Dual T-Tab Adapter (AP20MM2T)

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.


1 Insert the Pole into the Base

Begin by placing the pole into the base. Utilize the alley key included with the base and turn it clockwise to secure it in place.




2 Attaching the Adapter to a Pole

Insert the device holder to the 20mm ball compatible pole by loosening the knob and then retightening for a secure fit.




3 Fully Assembled

Refer to the image below for the full assembled product.



4 Adjust the Height of the Mount

To modify the height and angle of the mount, simply loosen the adjustment ring and adjustment knob. Once you've achieved the desired position, retighten them to secure it in place.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

